

NON-IBC SNOWDRIFT

This help section applies to all codes except IBC. For IBC Snow Drift information, see the IBC Snow Drift Help topic.

You need not be concerned if the adjacent building is lower than the new building or if the building is greater than 20 feet away.

Distance Below Adjacent Structure:

Specify how much taller the adjacent building is than the distance below building you are entering.

Linear Feet Affected:

Specify how many lineal feet of the new building is adjacent to the adjacent building.

Average Distance to Adjacent Structure:

Specify how far away the new building is from the adjacent building. If they are adjoining, use zero.

Example 1

The correct information for the example below would be:

Wall Affected: Front Sidewall

Average Distance Below Adjacent Structure: 4'-0"

Linear Feet Affected: 60'-0"

Average Distance to Adjacent Structure: 2'-0"

